

# GENERAL PURPOSE RESCUE TRAINING DUMMY

**LifeTec**<sup>®</sup>  
Rescue Training Dummies



The General Purpose dummies are our most popular models for common rescue scenarios such as height, confined space and urban rescue.



They have anatomically correct weight distribution and the uncanny 'feel' of an unconscious patient. Tough enough to be buried under a concrete slab, have steel lintels, trees or motor vehicles laid upon them, they can present realistic scenarios for rescuers.

The body carcass is heavy duty rot-proof canvas with all seams double stitched. High density polypropylene webbing provides extra strength and durability, especially at the high stress points. Machine-washable cotton/polyester overalls reinforced with the same webbing are fitted to all sizes of dummy. The ends of the overall arms are further protected with nylon reinforced PVC.

All dummies of 20kg and over are supplied complete with gum boots which also protect the legs if the dummy is dragged along the ground. Where the exercise involves constant dragging of the dummy we recommend fitting the Drag Protectors for additional protection, see the accessories section.

A strong webbing loop behind the head helps position and retrieve the dummy, and hang up the dummy to dry after use.

The shaped head allows the fitting of most types of immobilisation collars, and if the head gets badly soiled you can remove the red head cover and wash it.

These dummies can safely be used in scenarios with temperatures up to 100°C.

The General Purpose dummy is ideally suited for predominantly dry rescue conditions. If it does get wet it needs to be hung in a dry airy place to dry before storage. For a wet environment rescue scenario, such as a chemical spillage where the dummy may be doused, or storm drain or cave rescue where the dummy needs to lay constantly in water we recommend using the HazMat rescue dummy.

Available in weights and sizes from the 5kg Baby to the very heavy adult 100kg



5KG

10KG

20KG

30 | 50 | 70 | 100KG